

Maintenance and care of your Yale Safe

Yale recommend to regularly wipe the door, keypad, screen and a fingerprint sensor with a clean dry cloth.

Ensure that all batteries are changed once a year and if your safe is Smart, make sure that the app runs smoothly on your phone and that you can access and operate your safe remotely.